

Description of GSM2000 and GSM2 modules firmware versions.

Standard firmware versions of GSM2000 and GSM2 feature the following marking syntax:

GSM2000_n_nn.bin in the case of **GSM2000** module
and

GSM2_n_nn.bin in the case of **GSM2** module,

where: **n_nn** stands for firmware version, e.g. 2_24.

Special firmware versions are also available with the following extensions:

- | | |
|---------------------------------|---|
| _no_SMS_limit | - version with unlimited number of SMS notifications send by module. As standard, the daily limit can be set from 10 to 200 SMS. |
| _any_phone_controls_OUT1 | - this version allows setting ON output 1 of module when calling from any phone number not listed in the module's predefined phone numbers list. This special firmware may be used to control large parking entrance not requiring high security level, where anyone knowing phone number of the entrance control SIM can open the entrance gate.

NOTICE! If call is made from phone listed in the module's predefined phones list, only outputs assigned to this phone number will be set ON. |
| _only_OK | - firmware version allowing return SMS with "OK" notification send by module on any output control SMS send to the module. In standard firmware version, return SMS notifies state of all outputs. |